



EK7651H MAINTENANCE SCHEDULE

Item	Operating time	Before operation	After refueling	Daily (10h)	20h	30h	50h	200h	Before storage	Corresponding Part Number
Engine oil	Inspect/clean	○								
	Replace					○*1				
Tightening parts (bolt, nut)	Inspect	○								
Fuel tank	Clean/inspect	○								
	Drain fuel								○*3	
V-belt	Inspect/adjust	○								
Throttle lever	Check function		○							
Stop switch	Check function		○							
Cutting disc	Inspect	○		○						14" Cutting disc 966-144-120
Idle speed	Inspect/adjust			○						
Air Filter	Clean						○			Air filter 442165-6
Dust bag filter	Clean/replace				○					Dust bag filter 166106-5
Prefilter	Clean/replace			○						Prefilter 195945-6
Spark plug	Inspect (.020 in.)			○						Spark Plug CMR6H 168652-4
Cooling air passage and cylinder fins	Clean/inspect			○						
Fuel pipe	Inspect			○						
	Replace							○*2		Tube complete 168654-0
Fuel filter	Clean/replace						○			Fuel filter 163447-0
Valve clearance (intake valve and exhaust valve)	Inspect/adjust (.006 in.)							○*2		
Carburetor	Drain fuel								○*3	Carburetor 168815-2

*1 Perform initial replacement after 20h operation.

*2 For the 200 operating hour inspection, request Authorized Service Agent or a machine shop.

*3 After emptying the fuel tank, continue to run the engine and drain fuel in the carburetor.

*Note: Part numbers subject to change

OIL CHANGE FREQUENCY



PROPER OIL LEVEL

