

Model XSH04RB/ZB Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
001	458591-9	FRONT GRIP	1	
002	265995-6	TAPPING SCREW 4X18	1	PC.
006	265995-6	TAPPING SCREW 4X18	7	PC.
007	854N74-5	XSH04 NAME PLATE	1	
008	144251-6	INDICATION PLATE COMPLETE	1	PC.
009	140C50-2	MOTOR HOUSING COMPLETE	1	
	C10 263005-3	RUBBER PIN 6	2	PC.
	C20 817J81-5	CAUTION LABEL	1	
010	911263-2	PAN HEAD SCREW M5X40	3	PC.
011	419704-7	LOCK OFF BUTTON	1	PC.
012	651083-9	SWITCH C3XA-1PSPM	1	
013	231433-0	COMPRESSION SPRING 4	2	PC.
015	458594-3	SWITCH LEVER	1	
016	632L80-6	SWITCH UNIT	1	PC.
019	644809-6	TERMINAL	1	PC.
020	854N79-5	XSH04 SERIAL NO. LABEL	1	
021	629362-3	STATOR	1	
022	251517-8	TAPPING SCREW 4X40	2	PC.
023	620936-3	LED CIRCUIT	1	
024	620935-5	CONTROLLER	1	
025	458585-4	HANDLE COVER	1	
026	458586-2	BAFFLE PLATE	1	
027	458593-5	COVER	1	
028	519527-4	ROTOR ASS'Y	1	
	D10	INC. 29-31		
029	211012-0	BALL BEARING 606ZZ	1	PC.
030	240045-8	FAN 55	1	PC.
031	210059-1	BALL BEARING 6000DDW	1	PC.
032	233117-6	COMPRESSION SPRING 6	1	PC.
033	347400-6	SHAFT LOCK	1	
034	911223-4	PAN HEAD SCREW M5X16	1	PC.
035	458589-6	DUCT	1	
036	140D07-9	BLADE CASE COMPLETE	1	
	C10 213821-3	O-RING 26	1	PC.
037	262511-5	RUBBER SLEEVE 6	1	PC.
038	265115-2	+ PAN HEAD SCREW M5	1	PC.
039	211012-0	BALL BEARING 606ZZ	1	PC.
040	961052-5	RETAINING RING S-12	1	PC.
041	226192-9	HELICAL GEAR 49	1	
042	257173-2	RING 12	1	PC.
043	213512-6	O RING 39	1	PC.
044	135993-3	BEARING BOX ASSEMBLY	1	
	D10	INC. 43		
045	265034-2	+ COUNTERSUNK HEAD SCREW M5X16	2	PC.
046	211131-2	BALL BEARING 6001DDW	1	PC.
047	285843-3	BEARING RETAINER 19-29	1	PC.
048	327244-0	SPINDLE	1	
049	345469-4	THICKNESS RING	1	PC.
050	231832-6	TENSION SPRING 3	1	PC.

051	458587-0	SAFETY COVER	1	
052	961152-1	RETAINING RING (EXT) S-34	1 PC.	
053	224411-7	INNER FLANGE 35	1 PC.	
054	224409-4	OUTER FLANGE 35	1 PC.	
055	266925-0	HEX.SOCKET HEX.BOLT M6X18	1	
056	286036-5	CAP	1	
057	347399-5	LEVER PLATE	1	
058	257982-9	BOW STOP RING E-8	1 PC.	
059	264096-7	HEX. NUT M6	1	
060	267118-2	FLAT WASHER 6	1 PC.	
061	266737-1	FLAT HEAD SQ. NECK BOLT M6X20	1 PC.	
062	252631-3	SCREW M6	1 PC.	
063	942151-2	SPRING WASHER 6	1 PC.	
064	941151-9	FLAT WASHER 6	1 PC.	
065	161898-1	DEPTH GUIDE COMPLETE	1	
066	265939-6	FLAT HEAD SQ. NECK BOLT M6X14	1 PC.	
067	347401-4	REAR GUIDE PLATE	1	
068	265648-7	PAN HEAD SCREW M4X8	2	
069	252103-8	HEX. LOCK NUT M5-8	1 PC.	
070	345590-9	ANGULAR GUIDE	1 PC.	
071	256480-0	SHOULDER PIN 6-7	1 PC.	
072	318823-5	STOPPER	1 PC.	
073	213977-2	O RING 7	1 PC.	
074	266734-7	+ TRUSS HEAD SCREW M5	1 PC.	
075	251896-4	SCREW M5X20	1 PC.	
076	231007-7	COMPRESSION SPRING 6	1 PC.	
077	319715-1	ANGULAR PLATE	1	
078	941151-9	FLAT WASHER 6	1 PC.	
079	266735-5	HEX.BOLT M6X20	1 PC.	
080	271446-9	LEVER 45	1	
081	257982-9	BOW STOP RING E-8	1 PC.	
082	347397-9	BASE	1	
083	265085-5	+ COUNTERSUNK HEAD SCREW M4X8	2 PC.	
084	912212-2	COUNTERSUNK HEAD SCREW M5X12	4 PC.	
085	266436-5	H.S.SET SCREW(FLAT POINT)M5X8	3	
A01	783203-8	HEX. WRENCH 5	1 PC.	
A02	A-85092	T.C.T.SAW BLADE 165X24TX15.88	1 PC.	
A04	199230-9	DUST NOZZLE SET	1	
C10	911233-1	PAN HEAD SCREW M5X20	1 PC.	
A09	450128-8	BATTERY COVER	1 PC.	(XSH04RB)
A10	***DC18RC	DC18RC FAST CHARGER	1 PC.	(XSH04RB)
D10		COMPO-PARTS		
A11	197257-3	BATTERY BL1820B SET	2	(XSH04RB)
A12	831303-9	TOOL BAG	1	(XSH04RB)