



Model XRM02W Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
001	SE00000266	PCB-A ALL ASS'Y JP	1	PC.
	C10 SE00000267	CIRCUIT BOARD A	1	PC.
	C20 SE00000268	PCB-A DC_JACK ASS'Y	1	PC.
	C30 SE00000269	PCB-A PWR_WIRE ASS'Y	1	PC.
	C40 SE00000270	PCB-A BATT._DET ASS'Y	1	PC.
	C50 SE00000220	CIRCUIT BOARD C AUX-2 ASS'Y	1	PC.
002	SE09163102	SCREW M3X10	5	PC.
003	SE00000299	CIRCUIT BOARD C ASSY	1	PC.
004	SE09163102	SCREW M3X10	6	PC.
005	SE09090011	SCREW 1.7	13	PC.
006	SE020PC020	POWER BUTTON HOLDER	1	PC.
007	SE00000157	POWER BUTTON (GRY)	1	PC.
008	SE020PC030	PRESET BUTTON HOLDER	1	PC.
009	SE00000158	PRESET BUTTON (GRY)	1	PC.
010	SE09064161	SCREW M4X16	1	PC.
011	SE09163102	SCREW M3X10	2	PC.
012	SE09064161	SCREW M4X16	2	PC.
013	SE00000204	FRONT CABINET ASSY	1	PC.
015	SE09064161	SCREW M4X16	1	PC.
016	SE00000159	FRONT BUMPER	1	PC.
017	SE0338PC5Z	FRONT BAR	2	PC.
018	SE00000160	SCREW PTHE6X47(CR)	4	PC.
019	SE00000161	ROTARY KNOB	1	PC.
020	SE21B1110A	ROTARY KNOB RING	1	PC.
021	SE0335PC5Z	JACK COVER	1	PC.
022	SE09173106	HEX SCREW M3X10	1	PC.
023	SE00000162	BATTERY COVER BUMPER	1	PC.
024	SE09176166	HEX SCREW M6X16	2	PC.
025	SE09176166	HEX SCREW M6X16	2	PC.
026	SE00000165	REAR BUMPER	1	PC.
027	SE00000167	BATTERY COVER	1	PC.
028	SE09163102	SCREW M3X10	2	PC.
029	SE00000168	PACKING	1	PC.
030	SE00000169	SUPPORT BAR	1	PC.
031	SE00000170	SPRING-L	1	PC.
032	SE00000171	SPRING-R	1	PC.
033	SE09163102	SCREW M3X10	2	PC.
034	SE00000173	SPRING HOLDER-R	1	PC.
035	SE09163102	SCREW M3X10	2	PC.
036	SE00000175	SPRING HOLDER-L	1	PC.
037	SE00000031	BACK UP BATTERY COVER (WHITE)	1	PC.
038	SE021E9010	BATTERY CONTACT (+)	1	PC.
039	SE021E9020	BATTERY CONTACT (-)	1	PC.
040	SE021E9030	+/- BATTERY CONTACT ASS'Y	1	PC.
041	SE09163452	SCREW M3X45	1	PC.
042	SE00000176	SCREW PTHE6X20(CR)	1	PC.
043	SE00000178	HANDLE HOLDER (R)	1	PC.
044	SE00000179	HANDLE	1	PC.
045	SE00000181	HANDLE HOLDER (L)	1	PC.
046	SE00000176	SCREW PTHE6X20(CR)	1	PC.

047	SE09176166	HEX SCREW M6X16	1 PC.
048	SE00000184	SPRING	2 PC.
049	SE09994007	STEEL BALL	2 PC.
050	SE09994007	STEEL BALL	2 PC.
051	SE00000184	SPRING	2 PC.
052	SE09176166	HEX SCREW M6X16	1 PC.
053	SE00000187	HANDLE SUS-PLATE (R)	1 PC.
054	SE09163452	SCREW M3X45	1 PC.
055	SE00000189	REAR CABINET	1 PC.
056	SE00000067	LOCKER HINGER	1 PC.
057	SE00000190	BATTERY COVER LOCKER	1 PC.
058	SE021PC050	LOCKER FIXER PIN 63.8	1 PC.
059	SE021PC040	LOCKER FIXER PIN 79.5	1 PC.
060	SE00000191	ROD ANT (BLK)	1 PC.
061	SE021J9032	ROD ANT HOLDER	1 PC.
062	SE024J9050	PACKING	1 PC.
063	SE00000192	HANDLE SUS-PLATE(L)	1 PC.
064	SE021P0020	NUT	1 PC.
065	SE021PC100	ROD ANT TERMINAL	1 PC.
066	SE00000193	SCREW 3X10	2 PC.
067	SE024J9030	PACKING	1 PC.
068	SE024J9070	PACKING	4 PC.
069	SE09090023	SCREW M4X12	4 PC.
070	SE00000205	SPEAKER NET ASSY	1 PC.
071	SE024J9090	PACKING	4 PC.
072	SE024J9040	PACKING	4 PC.
073	SE9076146A	HEX SCREW M6X14	4 PC.
074	SE023PC020	EVA 25X18X5.5	1 PC.
075	SE021J9010	SPEAKER HOLDER	1 PC.
076	SE024PC040	PACKING	1 PC.
077	SE00000195	W/TIES 100MM	1 PC.
078	SE09163102	SCREW M3X10	1 PC.
079	SE09163102	SCREW M3X10	2 PC.
080	SE00000098	CLUSTER BATTERY HOLDER	1 PC.
081	SE09163102	SCREW M3X10	2 PC.
082	SE00000197	TERMINAL D	1 PC.
083	SE00000193	SCREW 3X10	2 PC.
084	SE00000199	SILICON RUBBER WASHER	2 PC.
085	SE00000193	SCREW 3X10	2 PC.
086	SE09163062	SCREW M3X6	2 PC.
087	SE00000200	TERMINAL C	1 PC.
088	SE023PC020	EVA 25X18X5.5	2 PC.
089	SE02311000	SPACER (A)	1 PC.
090	SE021J9010	SPEAKER HOLDER	1 PC.
091	SE024J9030	PACKING	1 PC.
092	SE024J9070	PACKING	4 PC.
093	SE09090023	SCREW M4X12	4 PC.
094	SE024J9090	PACKING	4 PC.
095	SE00000205	SPEAKER NET ASSY	1 PC.
096	SE024J9040	PACKING	4 PC.
097	SE9076146A	HEX SCREW M6X14	4 PC.
098	SE021PC030	BATTERY COVER LOCKER	1 PC.
099	SE00000193	SCREW 3X10	2 PC.
100	SE01620771	SPEAKER	1 PC.
101	SE01620771	SPEAKER	1 PC.
A01	SE00000077	AC ADAPTER 3A83PCF01B11	1 PC.