



## Model WT06Z Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty Unit
001	183L31-7	HOUSING SET	1
	C10 263002-9	RUBBER PIN 4	2 PC.
	C20 252126-6	HEX. LOCKING NUT M4-7	2 PC.
	D10	INC. 32	
002	266429-2	TAPPING SCREW 3X16	9 PC.
003	455053-8	F/R CHANGE LEVER	1 PC.
004	143975-1	SWITCH COMPLETE	1 PC.
	C10 424890-1	SWITCH COVER	1 PC.
005	422407-4	BUMPER	1 PC.
006	323675-1	PIN 4	1 PC.
007	140K41-1	HAMMER CASE COMPLETE	1
	C10 213882-3	O-RING 16	1 PC.
008	261159-0	NYLON WASHER 19	1 PC.
009	322045-1	CLIP	1 PC.
010	136089-3	ANVIL A ASS'Y	1
	D10	INC. 6,9	
011	327200-0	HAMMER	1 PC.
012	216019-1	STEEL BALL 3	24 PC.
013	267352-4	FLAT WASHER 22	1 PC.
014	232516-9	COMPRESSION SPRING 21	1
015	267813-4	WASHER 21	1 PC.
016	216002-8	STEEL BALL 4.8	2 PC.
017	327046-4	SPINDLE	1 PC.
018	227213-0	SPUR GEAR 17	2 PC.
019	268217-3	PIN 3.5	2 PC.
020	253052-2	FLAT WASHER 12	1 PC.
021	227316-0	INTERNAL GEAR 43	1 PC.
022	213479-8	O RING 33	1 PC.
023	140G75-0	BEARING BOX COMPLETE	1 PC.
	C10 213845-9	O-RING 13	1
024	266490-9	TAPPING SCREW PT 2X6	3 PC.
025	652069-6	FLAT HEAD SCREW M3X6	3 PC.
026	620998-1	CONTROLLER	1
027	629398-2	STATOR	1
028	619491-0	ROTOR	1 PC.
029	620999-9	LED CIRCUIT	1
030	644813-5	TERMINAL	1 PC.
031	855S25-1	WT06 SERIAL NO. LABEL	1
032	183L31-7	HOUSING SET	1
	C10 263002-9	RUBBER PIN 4	2 PC.
	C20 252126-6	HEX. LOCKING NUT M4-7	2 PC.
	D10	INC. 1	
033	140G52-2	SWITCH PLATE COMPLETE	1
	C10 818X19-7	SWITCH LABEL	1
034	855S18-8	WT06 NAME PLATE	1
035	818V52-7	CAUTION LABEL	1
A01	266622-8	+ TRUSS HEAD SCREW M4X12	1 PC.
A02	346909-5	HOOK	1 PC.