

# **In-Wall Relay Switch** Lite

Smart Relay (Zigbee) Instruction Manual

Rev A-090722

P/N SRB02A

\*Please see separate Smart Switch manual for complete instructions.





Smart Relay ×1

**Double Sided** Foam Pad ×1




Instruction Manual ×1

Device Identification QR Code (Zigbee)

### Product Introduction

Smart Relay Lite uses Zigbee wireless technology and may be used in different loads, including incandescent lamps, halogen lamps, LED lamps and fluorescent lamps. It is small in size and may be installed in the box of light fixtures. This device is compatible with standard Zigbee 3.0 gateway or devices for remote control and inter-operation.

Technical Specifications	
Model	SRB02A
Input Voltage	AC 85V~245V
Max. Load Power	AC 110V/1500W AC 220V/3000W
Min. Load Power	No limit
Type of Load	Lighting
Operating Temperature	0~40°C (32°~104°F)
Operating Humidity	5~85% RH
Wireless Connectivity	Zigbee 2.4GHz IEEE 802.15.4
Zigbee Profile	Zigbee 3.0
RF Characteristics	Operating frequency: 2.4GHz Range: 30m~60m Internal antenna
Product Size (L*W*H)	47.4mm * 39.3mm * 21.3mm (1.87in. x 1.55in. x 0.84in.)



### Installation Instructions

Caution: Read this manual before attempting to install the device! Using this product in a manner other than intended voids your warranty. Further, Evvr ApS is NOT liable for any damage incurred with the misuse of this product.

**Caution:** All installations of this device should be performed by a qualified or licensed electrician!

### Installation Instructions

Caution: Product must be installed on a 10A~16A line

Caution: Metal casings, mirrors, electrical appliances, etc., may affect, reduce, or interfere with wireless communication.



Warning: Turn OFF electrical power from the breaker box or electrical service panel before installing or servicing this product. Improper use or installation can cause SERIOUS INJURY, DEATH, or LOSS/DAMAGE OF PROPERTY.



### Caution:


Use this product in an indoor environment.

# Connect wires per wiring diagram as follows

Caution: If you have purchased a Smart Switch to use with it, please follow the installation instructions on the Smart Switch manual.

With **Smart Relay Lite**, you can turn a traditional lamp into a Zigbee smart lamp. It is recommended to install Smart Relay Lite near the lamp.


You can choose one of the two diagrams below to connect the wires according to your installation environment.



# Fix Smart Relay on a flat, cleaned surface

Stick the foam pad at the recommended position on the Smart Relay Lite and then place the relay on a flat, cleaned surface.

Turn ON electrical power and check if the wires are connected correctly. If they are correct, the indicator light will be on when the load light, the light(s) connected to the switch is on



LOAD

Important: The In-Wall Relay Switch Lite can be controlled from a smartphone when used with a Zigbee 3.0 gateway.

Note: Before pairing/re-pairing Smart Relay Lite, you need to set your Zigbee 3.0 gateway into inclusion/pairing mode with either methods.



Add devices and manually select the device type

Add devices by scanning the OR code on the device or manual

### Type of Connected Switch

Note: Panel mode only works when connected to Smart Switch Standard Edition. Double-click the reset button to switch between the three switching modes.

Switch	Indicator
toggle switch (device changes status when switch changes status)/smart switch panel	the indicator will blink purple once
toggle switch (contact closed - ON, contact opened - OFF)	the indicator will blink purple twice
momentary switch	the indicator will blink purple three times





# Set the Smart Relay Lite into inclusion/pairing mode



**RESET** button.









If the Smart Relay Lite is successfully paired, the indicator will show BLUE when the load light is on.

## Troubleshooting

## Smart Relay Lite pairing failed.

- The device may be too far from the gateway/coordinator or routing device, or there may be interference in the current network environment. Add routing devices or bring devices closer to the gateway/coordinator.
- The device is already joined to another gateway. Please restore the device to its factory default.

## Cannot be controlled by gateway/coordinator or other Zigbee devices.

The device may be installed in an unreasonable location, too far from the gateway or routing device, or there may be signal interference

- Please check whether there is strong electromagnetic field equipment near the wireless switch and check whether the equipment is installed in a closed metal housing or in a closed concrete wall.
- Add routing devices or bring devices closer to the gateway/coordinator.

## In case of power loss while the lights were on, the light status is on when power is restored?

Yes. The device will record the status of the light, and after the device is powered off, re-powering will restore the state before the device was powered off.

ECC ID: 2A68U-SRB02A



conditions:





This device complies with part 15 of the FCC

rules. Operation is subject to the following two

(1) this device may not cause harmful

interference, and (2) this device must accept

any interference received, including interference

Changes or modifications not expressly

approved by the party responsible for

compliance could void the user's authority to

NOTE: This equipment has been tested and

found to comply with the limits for a Class B

digital device, pursuant to part 15 of the FCC

Rules. These limits are designed to provide

reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can

radiate radio frequency energy and, if not installed and used in accordance with the

instructions, may cause harmful interference

to radio communications. However, there is no quarantee that interference will not occur in a

particular installation. If this equipment does

cause harmful interference to radio or

television reception, which can be determined

by turning the equipment off and on, the user is encouraged to try to correct the interference

that may cause undesired operation.

operate the equipment.





antenna or transmitter

This product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

by one or more of the following measures: Reorient or relocate the receiving antenna.

- Consult the dealer or an experienced

Important Announcement Important Note Radiation Exposure Statement This equipment complies with FCC radiation

exposure limits set forth for an uncontrolled

environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body. This transmitter must not be co-located or

operating in conjunction with any other

technician for help.

## Warranty Policy

For warranty information, please visit https://www.evvr.io/warrantv



Please contact us for any technical issue support@evvr.io

Rev A-090722 P/N SRB02A

# **Restore Smart Relay Lite to factory settings**



Lite from your Zigbee 3.0

gateway.

Remove the Smart Relay











If the Smart Relay Lite is successfully restored tofactory settings, the indicator will show **RED** when the load light is on.