



1. Remove your Presser foot, check with your owners manual if you are not on how to remove the foot.
2. Remove the screw as well if your Walking foot has a hole, not "U" Style opening.
3. Align the Walking Foot Activator bar onto the needle screw bar.
4. Align the mount to the screw hole and replace the screw. Remember to finger tighten the screw until you are sure it is threading on smoothly.