

Octo GX (OGX) manual

The Octo GX is a member of the [GX Product Family \(/live/venus-os:start\)](/live/venus-os:start). The Octo GX is the best fit for installations that have many MPPT Solar Chargers, as it has 10 VE.Direct ports.

The Octo GX is the communication-centre of your installation. It connects the components together and ensures they are working in harmony. Monitoring of live data, and changing settings is performed by using your smartphone (or other device) via our free-to-use Victron Remote Management Portal, VRM.

Note that this document is not finished yet. Whats needs doing is:

- photo
- link to product detail page: <https://www.victronenergy.com/panel-systems-remote-monitoring/octo-gx> [<https://www.victronenergy.com/panel-systems-remote-monitoring/octo-gx>]
- link to [Venus OS \(Operating System\) page Victron GX product range \(/live/venus-os:start\)](/live/venus-os:start)
- link to [Color Control GX manual \(/live/ccgx:start\)](/live/ccgx:start)
- copy bits & pieces over from the [Venus GX manual \[https://www.victronenergy.com/live/venus-gx:start\]](https://www.victronenergy.com/live/venus-gx:start) as that explain how to find / connect the device; Octo GX is same as Venus GX when it comes to connecting to it and such. It doesn't have a display, just like Venus GX, and dual wifi, also just like Venus GX.

