

# TI Stellaris LM3S3000 (SWD) Mass ISP Programming

**Application Note** 

DC04027

## NanoPlex<sup>™</sup> general description

NanoPlex NPS-06-01-04A Universal Relay ISP-Channel Multiplier allows the expansion of the number of channels of ISP-Programming tools, while also offering galvanic isolation. The total number of switched signals is 28. NanoPlex is used on PCBAs production lines, in ATE-controlled ISP programming. Thanks to its ultra-small size (only 51.0- x 66.5-mm), this NanoPlex model takes easly place in Test Fixtures. Designed for piggyback mounting, NanoPlex is universal and compatible with all types of ISP Programming tools.

## **Recommended Readings - Further Documentation**

Before starting, please study the following essential papers:

- NanoPlex NPS-06-01-04A Data Sheet
- NanoPlex NPS-06-01-04A Flexibility Application Note

*'NanoPlex NPS-06-01-04A Flexibility Application Note'* clearly describes NanoPlex **modularity** and how to deploy **multiple units** in order to create high-density ISP Programming Multipliers with an **unlimited number of channels**.


## Texas Instrument Stellaris LM3S3000 (SWD)

Signals required for ISP Programming are:

- SWCLK
- SWDIO
- RST (Optional)

The most convenient way to ISP program multiple instances of this device through NanoPlex is using this model in **2x8 operating mode**. 2 NanoPlex input channels are multiplied to 8 separated, galvanic isolated output channels.

On the following mode examples diagram, NanoPlex signal names are assigned with aliases (texts are in **bold**).



## **Truth table**

(the symbol ► stands for "connected to")

ENA	<b>A</b> 1	<b>A</b> 0	CH-IN-	00.SWCLK	00.SWDIO	00.RST	01.SWCLK	01. SWDIO	01.RST
				•	►	►	►	►	►
1	0	0	CH-OUT-	00.SWCLK	00.SWDIO	00.RST	01.SWCLK	01.SWDIO	01.RST
1	0	1	CH-OUT-	02.SWCLK	02.SWDIO	02.RST	03.SWCLK	03.SWDIO	03.RST
1	1	0	CH-OUT-	04.SWCLK	04.SWDIO	04.RST	05.SWCLK	05.SWDIO	05.RST
1	1	1	CH-OUT-	06.SWCLK	06.SWDIO	06.RST	07.SWCLK	07.SWDIO	07.RST
0	Х	Х	CH-OUT-	HI-Z	HI-Z	HI-Z	HI-Z	HI-Z	HI-Z

## **Operating sequence**

ENA = 1

A1 - A0 = "00"

CH-IN-00.SWCLK ► CH-OUT-00.SWCLK CH-IN-00.SWDIO ► CH-OUT-00.SWDIO CH-IN-00.RST ► CH-OUT-00.RST CH-IN-01.SWCLK ► CH-OUT-01.SWCLK CH-IN-01.SWDIO ► CH-OUT-01.SWDIO CH-IN-01.RST ► CH-OUT-01.RST

A1-A0 = "01"

CH-IN-00.SWCLK		CH-OUT-02.SWCLK
CH-IN-00.SWDIO	►	CH-OUT-02.SWDIO
CH-IN-00.RST		CH-OUT-02.RST
CU_TN_01 CWCTK	•	
CH IN OL.SWCLK		CH-OUT-03.SWCLK
		CH-OUT-03.SWCLK CH-OUT-03.SWDIO

A1 - A0 = ``10''

CH-IN-00.SWCLK		CH-OUT-04.SWCLK
CH-IN-00.SWDIO		CH-OUT-04.SWDIO
CH-IN-00.RST	►	CH-OUT-04.RST
CH-IN-01.SWCLK		CH-OUT-05.SWCLK
		CH-OUT-05.SWCLK CH-OUT-05.SWDIO

A1-A0 = ``11''

CH-IN-00.SWCLK ► CH-OUT-06.SWCLK CH-IN-00.SWDIO ► CH-OUT-06.SWDIO CH-IN-00.RST ► CH-OUT-06.RST CH-IN-01.SWCLK ► CH-OUT-07.SWCLK CH-IN-01.SWDIO ► CH-OUT-07.SWDIO CH-IN-01.RST ► CH-OUT-07.RST

## Connector pinout (aliases signals, top view)

Pin	Signal	Signal	Pin
01	CH-OUT-GND	CH-OUT-GND	40
02	CH-OUT-00.SWCLK	CH-OUT-04.SWCLK	39
03	CH-OUT-00.SWDIO	CH-OUT-04.SWDIO	38
04	CH-OUT-00.RST	CH-OUT-04.RST	37
05	CH-OUT-01.SWCLK	CH-OUT-05.SWCLK	36
06	CH-OUT-01.SWDIO	CH-OUT-05.SWDIO	35
07	CH-OUT-01.RST	CH-OUT-05.RST	34
08	CH-OUT-GND	CH-OUT-GND	33
09	CH-OUT-02.SWCLK	CH-OUT-06.SWCLK	32
10	CH-OUT-02.SWDIO	CH-OUT-06.SWDIO	31
11	CH-OUT-02.RST	CH-OUT-06.RST	30
12	CH-OUT-03.SWCLK	CH-OUT-07.SWCLK	29
13	CH-OUT-03.SWDIO	CH-OUT-07.SWDIO	28
14	CH-OUT-03.RST	CH-OUT-07.RST	27
15	CH-IN-00.SWCLK	A0	26
16	CH-IN-00.SWDIO	A1	25
17	CH-IN-00.RST	ENA	24
18	CH-IN-01.SWCLK	GND (*)	23
19	CH-IN-01.SWDIO	GND (*)	22
20	CH-IN-01.RST	Power	21

(\*) GND at pins 22/23 is used for both Power GND and CH-IN-GND.

## Using multiple NanoPlex NPS-06-01-04A units

NanoPlex NPS-06-01-04A product is modular by design. Several units can be deployed in order to set-up a very large, limitless channel-multiplier. The advantage of using more units is a faster and less expensive substitution.

Please read '<u>NanoPlex NPS-06-01-04A Flexibility Application Note</u>' to discover how to set-up a switching system with the **number of channels as high as your application requires**.

## **About Manta Systems**

Manta Systems is a high-tech company, global leader in high-density signal switching for In-System Programming (ISP) and Testing Systems. The company targets the electronic boards assembly market, where a high number of connections is required. Manta Systems flagship product is NanoPlex<sup>™</sup>, a series of Channels Multipliers for In-System Programming (ISP) and Testing instruments. NanoPlex is the **world's first universal tool** providing end-user with the possibility of having compact, easy-to-use, professional, reliable In-System Programming (ISP) and Testing Channel Multiplication functionality.

## Warranty

All Manta Systems products are covered by a **three-year warranty** against defects and workmanship from the purchase date. The warranty only covers products when properly installed and used.

## Orders

All NanoPlex<sup>™</sup> Series products are generally **off-the-shelf**. Shipping is within **24 hours** from order reception. **Free shipping** & 30-day money back guarantee.

## Disclaimer

Manta Systems is the owner of NanoPlex<sup>™</sup> tradename. Manta Systems reserves the right to make improvements to NanoPlex<sup>™</sup> Series and its documentation without notice. Information in this document is intended to be accurate and reliable. However, Manta Systems assumes no responsibility for its use; nor for any infringements of rights of third parties which may result from its use.

MANTA SYSTEMS WILL NOT BE LIABLE FOR DAMAGES RESULTING FROM LOSS OF DATA, PROFITS, USE OF PRODUCTS, OR INCIDENTAL OR CONSEQUENTIAL DAMAGES, EVEN IF ADVISED OF THE POSSIBILITY THEREOF.

Copyright © Manta Systems. All rights reserved. NanoPlex<sup>™</sup> is a tradename of Manta Systems. All other product or service names are the property of their respective owners.

www.mantasys.com info@mantasys.com

